



Note: Boom Stop version shown (19,21)

| No. | Description | Part No. |
|-----|------------------------|-----------|
| 1 | Retaining Ring (10/pk) | 00009M-03 |
| 2 | Dome Stop | 15097P-01 |
| 3 | Right Dome | 11696P-12 |
| 4 | Earseal (pair) | 18316G-02 |
| 5 | Dome Filter | 25629P-03 |
| 6 | Screws (10/pk) | 13180P-03 |
| 7 | Earphone Assembly | 10376G-17 |
| 8 | PCB Assembly | 18289G-13 |
| 9 | Dome Filter | 26475P-02 |
| 10 | Push Button Switch | 09851P-17 |
| 11 | Headband Spring | 25630P-01 |
| 12 | Headpad Assembly | 10133G-41 |
| 13 | Overhead Cord Assembly | 22607G-01 |
| 14 | Stirrup Assembly | 22378G-01 |

| No. | Description | Part No. |
|-----|--------------------------------|-----------|
| 15 | Switch Cap Kit | 41090G-13 |
| 16 | Switch Guard | 13148P-01 |
| 17 | Heat Shrinkable Tubing (10/pk) | 18326G-01 |
| 18 | Left Dome (Non-Boom Stop) | 11696P-28 |
| 19 | Left Dome (Boom Stop) | 11696P-84 |
| 20 | Boom Guide Kit (Non-Boom Stop) | 12840G-01 |
| 21 | Boom Guide Kit (Boom Stop) | 12840G-20 |
| 22 | Microphone Cord Assy Kit | 10405G-05 |
| 23 | Communication Cord Assy Kit | 18028G-34 |
| 24 | Microphone Boom Assy | 12765G-08 |
| 25 | DC-1A Microphone w/Cord | 12948G-14 |
| 26 | Microphone Cord Assembly | 10516G-14 |
| 27 | Mic Protector | 40062G-06 |
| 28 | DC-1A Microphone | 18920G-04 |

ELECTRICAL SCHEMATIC MODEL H3332

