


PARTS LIST
MODEL U3815



No.	Description	Part No.
1	Knob	09347P-15
2	Shaft Seal Nut	13145P-05
3	Volume Control 5K	09349P-30
4	Connector (4 Socket)	00084M-04
5	Push Button Guard	26553P-01
6	Neoprene Washer (10/pk)	18900G-39
7	Push-To-Talk Switch	09851P-28
8	Jack Cover (with Nut)	09518P-04
9	Neoprene Washer (10/pk)	18900G-39

No.	Description	Part No.
10	Headset Jack	09228P-03
11	Connector (5 Socket)	00121M-01
12	Gasket	13176P-03
13	Screws and Nuts (4 ea.)	18900G-01
14	Cap (and nylon cord)	13238P-01
15	Connector (6 Socket)	00084M-05
16	Mounting Kit (4 ea.)	09865P-03
17	Grommet (4 ea.)	18900G-08
18	Box	26497P-21